



# i-Pilot LINK

## COMPATIBLE HUMMINBIRD UNITS & SD CHIPS



### HUMMINBIRD UNIT COMPATIBILITY



#### ONIX SERIES

- ONIX 10 SI
- ONIX 10ci Combo
- ONIX 8 SI
- ONIX 8ci Combo



#### 1100 SERIES

- 1157c Combo
- 1158c Combo
- 1158c DI Combo\*
- 1158cx XD Combo
- 1159ci HD Combo‡
- 1159ci HD DI Combo\*\*
- 1159ci HD XD Combo‡
- 1197c SI Combo
- 1198c SI Combo
- 1199ci HD SI Combo‡



#### 900 SERIES

- 958c Combo
- 958c HD Combo
- 958c DI Combo\*
- 958c HD DI Combo\*
- 958cx HD XD Combo
- 959ci HD Combo‡
- 959ci HD DI Combo\*\*
- 959ci HD XD Combo‡
- 998c HD SI Combo
- 998c SI Combo
- 999ci HD SI Combo‡



#### 800 SERIES

- 858c Combo
- 858c HD Combo
- 858c DI Combo\*
- 858c HD DI Combo\*
- 858cx HD XD Combo
- 859ci HD Combo‡
- 859ci HD DI Combo\*\*
- 859ci HD XD Combo‡
- 898c SI Combo
- 898c HD SI Combo
- 899ci HD SI Combo‡



#### 700 SERIES

- 788ci HD XD Combo‡
- 788ci HD DI Combo\*\*
- 788ci HD Combo‡
- 798ci HD SI Combo‡

### SD CARD COMPATIBILITY



Humminbird LakeMaster SD Card



Humminbird AutoChart SD Card

The Follow the Contour function of i-Pilot Link requires an i-Pilot Link enabled LakeMaster SD Card or a Humminbird AutoChart SD Card. Look for the i-Pilot Link logo on the packaging.

\*Minn Kota motors with built in Universal Sonar 2 (including those with i-Pilot Link) are not compatible with Humminbird's Down Imaging Sonar. An external [XTM 9 WIDE DI 20 T](#) transducer would be required for all sonar readings with these Humminbird models: 1159ci HD DI, 1158c DI, 959ci HD DI, 958c HD DI, 958c DI, 859ci HD DI, 858c HD DI, 858c DI. An external [XTM 9 DI 25 T](#) transducer would be required for the 788ci HD DI.

‡These units require Ethernet Adaptor Cable AS EC QDE

